

CONTROL UNIT FOR DIESEL ENGINE TYPE DCA-120/10

RESERVED TO THE
MANUFACTURER



TECHNICAL PROGRAMMING MANUAL

BRIEF INSTRUCTIONS

READ:

- selection of functions on page 5
- when terminal 65 are connected is necessary programming ADJUSTMENT WITH CHARGING ALTERNATOR FREQUENCY (W) see page 6.



PARMA ITALY


Tel. +39 0521/772021

Fax +39 0521/270218

REPLACING OF CONTROL UNIT

Before replacing the control unit we recommend transferring all the programming to the new control unit, **if this is not carried out**, the new control unit will operate with the factory-set programming.


PROCEDURE TO BE CARRIED OUT WITH ENGINE STOPPED AND CONTROL UNIT **NOT** SUPPLIED WITH POWER



TRANSFER OF PROGRAMMING OPERATIONS

It is possible to transfer the programming operations of a standard control unit onto several memories. We advise you not to exceed fifty transfers.

Example:



Switch off the power to the control units.

2. Remove the memory from the control unit A.
3. Remove the memory from the control unit B.
4. Insert the memory B in the control unit A.
5. Supply power to the the control unit A.
6. The following is read "UPDATE CONTROL UNIT?".
7. Press the **STOP** button.
8. The following is read: "SAVE DATA TO MEMORY?".
9. Press the **START** button.
10. The following is read: "END OF TRANSFER".
11. Switch off the power to the control unit A.
12. Remove the memory B from control unit A.
13. Insert the memory B in the control unit B.
14. Supply power to the the control unit B.
15. The following is read: "UPDATE CONTROL UNIT?".
16. Press the **START** button.
17. The following is read: "END OF TRANSFER".
18. Repeat from point 3 for memories C and D.

RESTORATION OF FACTORY PROGRAMMING OPERATION OF THE PROGRAMMING OPERATIONS: ENGINE AND PROGRAMMABLE TIMES

Disconnect the battery power supply to the control unit (we suggest opening the protection fuse).

Supply power to the control unit again, press at the same time (within 8 sec) the three keys, wait until STANDARD PROGRAMMING is written on the display.




CONTROL UNIT STAND BY

After 30 seconds of inactivity, the control unit enters STAND BY state, switching off completely all the signalling (led and display).


To exit STAND BY state press one of the buttons.

TECHNICAL PROGRAMMING



LANGUAGE CHOICE

LANGUAGE SELECTION. The language set up in the factory is **ITALIAN**; the languages that can be selected are: **ENGLISH - FRENCH - GERMAN - SPANISH** and **PORTUGUESE**.




CAN Bus

ENGINE TYPE AND MAKE PROGRAMMING OPERATIONS

Protocol CAN Bus SAE J1939

CHOICE OF MAKE AND TYPE OF ENGINE equipped with control unit for electronic control of the injection system.




RPM VARIATIONS:


RELAYS acceleration and deceleration of the engine are managed by the relays present in DCA-120/10

SPEED 123 function active only in SCANIA electronic engines, allows the speed of the engine to be changed by pressing the hare and tortoise buttons.


SETPOINT function active only in SCANIA engines, on pressing the hare button the RPM reach the SETPOINT value. See description on page 3 of the user manual.



RPM SPEED: active only in SCANIA engines, it is the range of revs the engine goes to in SETPOINT mode.



RPM DEVIATION: active only in SCANIA engines, it can range from -120 to + 120 RPM, by default the setting is 0 RPM. This is the value that is added to or subtracted from the RPM speed, for example if 68 RPM is set and the RPM speed is 1800 RPM, the engine will go to 1868 RPM.






READ BEFORE USING THE CONTROL UNIT


CHOICE OF FUNCTIONS

WITH STOPPING SYSTEM "ENERGIZED IN STOP MODE" consult our technical office.


STOPPING SYSTEMS  Press to display

ENERGIZED IN STOP MODE
ENERGIZED IN RUN MODE

STOP **START**
Press to choose


Factory setting
ENERGIZED IN RUN MODE  Press and wait for PROGRAMMED to be written


WEEKLY AUTOMATIC TEST. When **WEEKLY AUTOMATIC TEST ON** programming has been completed, with control unit in automatic mode, the engine carries out immediately the test cycle.

WEEKLY AUTOMATIC TEST  Press to display

ENGAGED
OFF


STOP **START**
Press to choose


Factory setting
OFF  Press and wait for PROGRAMMED to be written

BATTERY VOLTAGE  Press to display

24 V
12 V


STOP **START**
Press to choose

Factory setting
12 V  Press and wait for PROGRAMMED to be written

PROTECTIONS IN MANUAL  Press to display


WITHOUT STOP
WITH STOP

STOP **START**
Press to choose

Factory setting
WITH STOP  Press and wait for PROGRAMMED to be written


FUNCTION OPTION TO BE ASSOCIATED WITH THE INPUT 41
Input 41 can be used in two ways:


- 1) Fully programmable **protection input available** (times, polarities, possibility of stopping and message regarding the anomaly)
or
- 2) **Inhibition of control unit protection** devices when the input is connected to ground, all the protection devices of the control unit are switched off. No switching off is possible for: **OVERSPEED** and **EMERGENCY**.

INPUT 41  Press to display

INHIBITION OF PROTECTIONS
PROTECTION AVAILABLE


STOP **START**
Press to choose

Factory setting
PROTECTION AVAILABLE  Press and wait for PROGRAMMED to be written


INDICATION OF ANOMALIES  Press to display

NUMERIC CODE
WRITTEN INDICATION

STOP **START**
Press to choose


Factory setting
WRITTEN INDICATION  Press and wait for PROGRAMMED to be written

CHOICE OF UNIT OF MEASUREMENT. It is possible to select the units of measurement Kpa - °F - BAR - °C.

CHOICE OF UNIT OF MEASUREMENT  Press to display

Kpa ←
°F

STOP **START**
Press when the arrow is next to the unit of measurement to be modified.

Factory setting
BAR
°C  Press and wait for PROGRAMMED to be written


RUNNING ENGINE THRESHOLD, TACHOMETER AND OVERSPEED ADJUSTMENTS

SIGNALS COMING FROM THE CHARGING ALTERNATOR

Adjustment with control unit connected to D+ (control unit terminal 66) of the pre-excitation alternator.

RUNNING ENGINE THRESHOLD ADJUSTMENT

Normally no adjustment needs to be carried out, but if it is necessary to carry it out: **stop the engine.** Choose the threshold voltage coming from the charging alternator (terminal D+) Adjustment field 3÷12 (12V) 6÷24 (24V) Factory setting 7V 14V




ADJUSTMENTS WITH CHARGING ALTERNATOR FREQUENCY (W)

Adjustment with control unit connected to W (control unit terminal 65) of the pre-excitation alternator or to the yellow wire of the permanent magnet alternator.

TACHOMETER ADJUSTMENT

Run the engine at a constant and known rpm value (for example by means of a portable revolution counter).

NECESSARY PROGRAMMING (With connected control unit terminal 65)




SIGNALS COMING FROM THE PICK-UP MAGNETIC TRANSDUCER (control unit terminals 63 and 64)

TACHOMETER ADJUSTMENT

Run the engine at a constant and known rpm value (for example by means of a portable revolution counter).

do not connect terminal 65 with this signal.

NECESSARY PROGRAMMING (With connected control unit terminals 63-64)




ENGINE RUNNING, OVERSPEED AND UNDERSPEED

With signals coming from W of the charging alternator (control unit terminal 65)


PICK-UP (control unit terminals 63 - 64)

RUNNING ENGINE THRESHOLD ADJUSTMENT


Normally no adjustment needs to be carried out, but if it is necessary to carry it out: **stop the engine.**



OVERSPEED ADJUSTMENT



UNDERSPEED ADJUSTMENT is factory excluded




SIGNALS COMING (CAN Bus protocol SAE J1939) FROM THE ENGINE EQUIPPED WITH CONTROL UNIT FOR THE ELECTRONIC CONTROL OF THE INJECTION SYSTEM.


With this signal do not connect the terminals 63 - 64 - 65.

Running engine threshold adjustment

Normally no adjustment needs to be carried out, but if it is necessary to carry it out: **stop the engine.**



PREVENTIVE MAINTENANCE

The control panel manages three fixed-time indications and one cyclical. The indication numbers 1, 2 and 3 are of prefixed time and trigger only once, when the hour-meter reaches the programmed value. The indication number 4 is cyclical and triggers after the programmed hours and their integer multiples. Request for maintenance is indicated by: the flashing of the hour-meter, the intermittent lighting of the yellow warning light  and the message on the display.

Example 1: Indication 4 is programmed at 100. The indication triggers after 100, 200, 300, 400 ... hours

Example 2: Indication 1 is programmed at 100. The indication triggers at 100 hours, and does not trigger again.

The factory value for all indications is zero. The maintenance operations are programmed by the engine manufacturer during testing. The maximum value is 59999 hours.

ACCESS TO THE PREVENTIVE MAINTENANCE PROGRAMMING

zero hours preventive maintenance not activated

example 500h → NO STOP

Press to display

Decreases STOP START Increases

Press when the arrow is next to the value to be increased

STOP, when maintenance has expired it stops the engine, enables the general alarm and prevents further startups. NO STOP, enables the general alarm for 10 seconds.

Press again to change the maintenance number 1 - 2 - 3 - 4 (cyclical)

500h NO STOP

Press and wait for PROGRAMMED to be written

The expired maintenances are considered anomalies

| anomalies codes | |
|-----------------|-----------------------------|
| ALARM 111 | preventive maintenance N. 1 |
| 112 | N. 2 |
| 113 | N. 3 |
| 114 | N. 4 |

EXPIRED MAINTENANCES DELETING

MAINTENANCES NOT EXPIRED DELETE MAINTENANCE 1?


Press to display

Press again to change the number of the expired maintenance operation

DELETE MAINTENANCE 1?

STOP START

To delete press simultaneously and wait for PROGRAMMED to be written

The warning light  switches off when all the expired maintenances have been deleted.

RESETTINGS AND CHANGE

RESETTING OF STARTING FAILURES COUNTER

RESET STARTING FAILURES?

Press to display

RESET STARTING FAILURES?

STOP START

To reset press simultaneously and wait for PROGRAMMED to be written

RESETTING OF STARTING COUNTER

RESET STARTUP COUNTER?

Press to display

RESET STARTUP COUNTER?

STOP START

To reset press simultaneously and wait for PROGRAMMED to be written

CHANGE OF INDICATED HOURS. When you change the value of the hour meter the preventive maintenance programming must be done again.

VARIAZIONE CONTAORE

Press to display the hours to be changed

1 2 3 4 5h ←

STOP START

Press to change the hours

1 2 3 4 5h

Press and wait for PROGRAMMED to be written

RESETTING OF LITRES OF FUEL USED

RESET FUEL LITRES?

Press to display

RESET FUEL LITRES?

STOP START

To reset press simultaneously and wait for PROGRAMMED to be written

RESETTING ANOMALY CAN BUS. Valid only with CAN-BUS connection. The faults stored in the engine control unit are restored through this command. Not all engine control units support this command, and therefore the actual operation of this function is not guaranteed.

RESET ANOMALY CAN BUS?

Press to display

RESET ANOMALY CAN BUS?

STOP START


To reset press simultaneously and wait for PROGRAMMED to be written

RELAYS THAT CAN BE ASSOCIATED

It is possible to associate a relay with each of the protection devices listed in the basic table or with the functions included in this list:

| DESCRIPTION OF DISPLAY | MEANING |
|--|---|
| • WEEKLY AUTOMATIC TEST | Weekly test in progress |
| • DAILY START TIMER | Starting by timer |
| • CALL | Starting on closing of the call contact |
| • STARTING WITH GSM | Starting with GSM telephone |
| • MANUAL STARTING | Manual starting |
| • MODE AUT • MODE MAN • MODE OFF | Function selected |
| • STOP | Stopping in progress |
| • RUNNING ENGINE | The engine has started |
| PREVENTIVE MAINTENANCE N. 1 " 2 " 3 " 4 | Expired maintenances |


OUTPUTS THAT CAN BE ASSOCIATED



TWO RELAYS THAT CAN BE ASSOCIATED WITH THE FUNCTIONS AND PROTECTION DEVICES LISTED ON PAGE 8 OF THE TECHNICAL PROGRAMMING OPERATIONS MANUAL

PROGRAMMING

PROGRAMMING OF 2 RELAYS. The 2 relays are energized when the corresponding fault or the selected function is detected




PROGRAMMABLE TIMES


| DESCRIPTION | SECONDS | |
|---|------------------------------------|---------------------------|
| | ADJUSTMENT FIELD | FACTORY SETTING |
| PREHEATING TIME - Preheating operation time | 0÷60 | 0 (preheating off) |
| STARTING TIME Starting attempt operation time | 5÷25 | 5 |
| PAUSE TIME Pause between starting attempts | 1÷20 | 5 |
| STOPPING TIME - Stopping system operation time after the running engine signal has disappeared | 1÷55 | 20 |
| STARTUP DELAY AFTER CLOSING OF CALL - On closing the call contact and when the delay time is up, the start up begins | 1÷600 | 1 |
| STOPPING DELAY AFTER OPENING OF CALL - On opening the call contact and when the delay time is up, the engine stops | 1÷600 | 1 |
| GENERAL ALARM INSERTION TIME - Number 350 means continual operation without time limits | 10÷350 | 350 (continual operation) |
| ENGINE HEATING TIME - Engine acceleration time | 0÷300 (zero operation excluded) | 180 |
| ENGINE COOLING TIME - Engine deceleration time. | 0÷300 (zero operation excluded) | 180 |
| WEEKLY AUTOTEST TIME - When the test time is up, the engine stops | 1÷60 minutes | 3 minutes |

PROGRAMMABLE TIMES


PREHEATING TIME. Preheating operation time. 0 sec. preheating off.




STARTING TIME. Starting attempt operation time.



PAUSE TIME. Pause between starting attempts




STOPPING TIME. Stopping system operation time after the running engine signal has disappeared.




STARTUP DELAY AFTER CLOSING OF CALL.

On closing the call contact and when the delay time is up, the start up begins.




STOPPING DELAY AFTER OPENING OF CALL.

On opening the call contact and when the delay time is up, the engine stops.




GENERAL ALARM CONNECTION TIME.


Number 350 means continual operation without time limits.




ENGINE HEATING TIME. After start the engine remains decelerated for this time.



ENGINE COOLING TIME. The engine is decelerated for this time before stopping.



WEEKLY AUTOTEST TIME. When the test time is up, the engine stops.



BASIC TABLE PROGRAMMING

| ALARM CODE | ANOM- ALY ENGINE FUNC- TIONS AND PRO- TECTIONS (DISPLAY INFOR- MATION) | INSTANT OF ACTIVATION (SECONDS) | THRESHOLDS | | INTERVENTION DELAY | | STORES THE FUNCTION | STOP | | INTERVENTION OCCURS WHEN: |
|---------------|---|---------------------------------------|--|---|--------------------------|-------------------------|------------------------|--------------------|--------------------|--|
| | | | ADJUST- MENT FIELD | FACTO- RY SET- TING | ADJUST- MENT RANGE | FACTORY SETTING | | PRO-GRAM- MABLE | FACTORY SETTING | |
| | | | | | | | | | | |
| 120 | BATTERY UNDER-VOLTAGE | ALWAYS ACTIVE | 8+12(12V) 16+24(24V) | 11 (12V) 22 (24V) | 1+5 | 2 | YES | DOES NOT STOP | | Battery voltage remains lower than the programmed threshold for the whole of the intervention delay time. |
| 121 | BATTERY OVER-VOLTAGE | " | 12+18(12V) 24+36(24V) | 16 (12V) 32 (24V) | = | 5 | YES | YES | WITHOUT STOP | Battery voltage exceeds the programmed threshold for the whole of the intervention time. |
| 123 | OVER-HEATING WARNING | " | 90+140°C | 95°C | = | = | YES | WITHOUT STOP | | The temperature detected by the transmitter exceeds the set threshold. |
| 124 | ENGINE OVER-HEATING | " | 90+140°C | 100°C | = | = | YES | STOPS | | |
| 125 | OVER-HEATING DETECTED BY THERMOSTATIC SWITCH | WITH RUNNING ENGINE | | | = | = | YES | STOP | | The temperature exceeds the threshold set by the thermostatic switch. No programming is possible. |
| 129 | FUEL RESERVE | ALWAYS ACTIVE | 0+99% | 10% | 1+5 | 1 | NOT | ALWAYS ACTIVE | | The fuel level remains lower than the threshold for the whole of the intervention delay time. |
| 130 | NO FUEL | " | 0+99% | 1% | 1+20 | 3 | YES | YES | WITH STOP | |
| 131 | LOW OIL PRESSURE WARNING | 10 AFTER DETECTION OF RUNNING ENGINE | 0+6bar | 0,5 bar | 1+5 | 1 | YES | NOT | DOES NOT STOP | The pressure detected by the transmitter remains lower than the programmed threshold for the whole of the intervention delay time. |
| 132 | LOW OIL PRESSURE | 10 AFTER DETECTION OF RUNNING ENGINE | = | = | = | IMMEDIATE | YES | NOT | STOP | The pressure is lower than the threshold set by the pressure switch. (No programming is possible). |
| 133 | STOPPING FAILURE | AFTER THE STOP COMMAND | = | = | = | 60 | YES | | | See description on page 4 of the instructions and user manual. (No programming is possible). |
| 135 | LOW COOLANT LEVEL | ALWAYS ACTIVE | = | = | = | 5 | YES | STOPS | | The cooling liquid falls below the electrode and the intervention delay time has elapsed. (No programming is possible). |
| 136 | CHARGING ALTERNATOR FAULT (belt breakage) | 10 AFTER DETECTION OF RUNNING ENGINE | = | = | = | 3 | YES | YES | WITHOUT STOP | Alternator does not recharge the battery and the intervention delay time has elapsed. |
| 137 | NUMBER OF STARTING ATTEMPTS (STARTING FAILURE) | ALWAYS ACTIVE | 1+10 STARTINGS | 4 STARTINGS | = | = | YES | STOP | | See description on page 3 of the instruction and user manual. |
| 138 | ENGINE START IN CASE OF LOW BATTERY CHARGE | ALWAYS ACTIVE | Minimum threshold 12,2+12,7 24,4+25,4 Maximum threshold 13,5+14,5 27+29 | 12,4(12V) 24,8 (24V) 13,6(12V) 27,2(24V) | 900+ 7200 | 1200 (20 minutes) | NOT | | | The voltage detected at the battery is lower than the minimum threshold (the engine starts). The voltage exceeds the maximum threshold after the intervention delay time (the engine stops). |
| 139 | OVER-SPEED | " | 1000 + 4000 RPM | 4000 RPM | = | 2 | YES | STOP | | The speed exceeds the programmed threshold at least two seconds, stops the engine. |
| 140 | INTERRUPTED FUEL FLOAT | " | = | = | = | = | NOT | DOES NOT STOP | | The circuit of the fuel float is interrupted (no programming is possible). |
| 144 | INTERRUPTED PICK-UP | ALWAYS ACTIVE | = | = | = | = | = | DOES NOT STOP | | The circuit of PICK-UP is interrupted. No programming is possible. |
| 145 | UNDER-SPEED | 10 AFTER THE THRESHOLD IS EXCEEDED | 0+3000 RPM | 0 RPM | 1+10 | 5 | YES | YES | DOES NOT STOP | The speed remains lower than the programmed threshold for the whole of the intervention delay time. |
| 146 | ANOMALY PICK-UP | " | = | = | = | 1 | = | DOES NOT STOP | | PICK-UP is an anomaly. No programming is possible. |
| 419 | EMERGENCY STOP | " | = | = | = | = | = | STOP | | The emergency button is pressed. (No programming is possible). |
| 421 | AVAILABLE | | | | | | | | | Available fully programmable anomaly see on page 13. |
| 430 | CAN Bus ANOMALY | ALWAYS ACTIVE | = | = | = | = | = | DOES NOT STOP | | The DCA-120 does not communicate with the control unit of the engine. |
| 440 | MEMORY ERROR | " | = | = | = | = | = | DOES NOT STOP | | During the normal operation the memory is no longer used. |

| BASIC TABLE PROGRAMMING | | | | | | | | | | | |
|-------------------------|------------------------------|--|---------------------------------|------------------|-----------------|--------------------|-----------------|---------------------|--------------|------------------|---|
| ALARM | ANOMALY | ENGINE FUNCTIONS AND PROTECTIONS (DISPLAY INFORMATION) | INSTANT OF ACTIVATION (SECONDS) | THRESHOLDS | | INTERVENTION DELAY | | FUNCTION STORES THE | STOP | | INTERVENTION OCCURS WHEN: |
| | | | | ADJUSTMENT FIELD | FACTORY SETTING | ADJUSTMENT RANGE | FACTORY SETTING | | PROGRAMMABLE | FACTORY SETTINGS | |
| 441 | MEMORY NOT INSTALLED | | ALWAYS ACTIVE | = | = | = | = | = | | DOES NOT STOP | The memory is no longer recognized by the control unit. |
| 443 | INCORRECT FUEL FLOAT TABLE | | " | = | = | = | = | = | | DOES NOT STOP | Just one value or non-increasing or decreasing values are programmed. |
| 446 | OIL PRESS. TABLE NOT CORRECT | | " | = | = | = | = | = | | | |
| 447 | OIL TEMP. TABLE NOT CORRECT | | " | = | = | = | = | = | | | |

N. B.: all the programming is to be carried out with the engine off. ANOMALY CODES: ALARM 111-112-113-114 (see on page 8).

With CAN Bus active, anomaly codes 123-124-131 are managed only by the engine control unit (CAN Bus).

ENGINE PROGRAMMING

BATTERY UNDERVOLTAGE. The engine does not stop.

BATTERY OVERVOLTAGE. The protection device is factory-programmed to not stop. Non-adjustable intervention delay of 5 sec.

PROTECTION ENGAGEMENT DUE TO ENGINE OVERTEMPERATURE

The temperature is sensed by the (TEMPERATURE) TRANSMITTER and is programmable. The protection is adjusted according to two levels: it is engaged when they are exceeded. The alert level is programmed as a warning; the other level is programmed to stop the engine (the overtemperature is sensed by the thermostat which always causes the engine to stop).

ENGINE OVERHEATING WARNING.

OVERHEATING.

FUEL RESERVE. The engine does not stop. **NO FUEL.** It is possible to programme the stop; it is factory-programmed to stop.

LOW OIL PRESSURE WARNING. (this is the pressure sensed by the pressure transmitter)

It is programmed as a warning and does not cause the engine to stop. (This is the low pressure sensed by the pressure switch which causes the motor to stop).

ANOMALY OF THE CHARGING ALTERNATOR. It is possible to programme the stop; it is factory-programmed to stop.

ENGINE PROGRAMMING

NUMBER OF STARTUP ATTEMPTS. 10 programmable startup attempts. (Starting failure).

Number of attempts

NUMBER OF STARTUP ATTEMPTS Press to display

STOP **START** Press to choose the number of startup attempts.

Press and wait for PROGRAMMED to be written

Setting of speed of ACCELERATION AND DECELERATION

The speed variator completes its maximum travel in 60 mm.

It adjusts the engine speed in pulses followed by pauses. Acceleration and deceleration can both be adjusted, the value to set ranges from 1 to 10: 1 - SLOW MODE, 10 - FAST MODE.

WE ADVISE AGAINST the use of speed variators where **PRECISE** setting OF THE NUMBER OF REVOLUTIONS is necessary

ACCELERATION SPEED

Starts at the end of **ENGINE HEATING**. Ends when working speed is reached.

ACCELERATION SPEED Press to display

MODE

STOP **START** Press to choose

Factory setting Press and wait for PROGRAMMED to be written

DECELERATION SPEED

Starts after opening of the **CALL**. After deceleration has ended **ENGINE COOLING** starts.

DECELERATION SPEED Press to display

MODE

STOP **START** Press to choose

Factory setting Press and wait for PROGRAMMED to be written

RPM TOLERANCE IN AUTOMATIC MODE. Takes the accelerator back to the chosen working speed with a tolerance of ± 50 RPM. Setting field 20÷150 RPM.

RPM TOLERANCE IN AUTOMATIC Press to display

Tolerance

STOP **START** Press to choose the number of revolutions

Press and wait for PROGRAMMED to be written

CHANGES IN RPM : it is used to program changes in the rpm by pressing button or when the **MOTOR SPEED 1-2-3** function is enabled. The factory value is 10 rpm. The range is between 5 and 50 rpm.

CHANGES IN RPM Press to display

STOP **START** Press to choose the number of revolutions

Press and wait for PROGRAMMED to be written

ENGINE START WITH BATTERY WITH LOW CHARGE. (With control unit in automatic mode).

Starts or stops the generating set in relation to the voltage detected at the battery terminals.

START WITH FLAT BATTERY Press to display

Minimum threshold Maximum threshold

Intervention delay

STOP **START** Press when the arrow is next to the parameter to be modified

Press and wait for PROGRAMMED to be written

RADIATOR LIQUID LEVEL PROBE SELECTION

RADIATOR LEVEL PROBE Press to display


REVERSED OPERATION **NORMAL OPERATION** Factory setting **NORMAL OPERATION** Press and wait for PROGRAMMED to be written

STOP **START** Press to choose


DESCRIPTION

| SELECT PROBES | MESSAGE SHOWN ON THE DISPLAY | SELECT PROBES | MESSAGE SHOWN ON THE DISPLAY |
|---------------|------------------------------|---------------|------------------------------|
| | REVERSED OPERATION | | NORMAL OPERATION |

CHOICE OF THE PREVIOUSLY PROGRAMMED TEMPERATURE AND PRESSURE TRANSMITTERS



| | 25°C | 50°C | 70°C | 80°C | 85°C | 90°C | 95°C | 100°C | 120°C | 130°C | OHM |
|-----------------------------|------|------|------|------|------|------|------|-------|-------|-------|-----|
| TPO/402 | 896 | 365 | 196 | 145 | 127 | 110 | 97 | 85 | 53 | | |
| VDO 120 | 548 | 287 | 95 | 69 | 59 | 51 | 44 | 38 | 22 | 17 | |
| VDO 150 | 498 | 323 | 183 | 113 | 96 | 83 | 73 | 62 | 37 | 29 | |
| BERU | | 1100 | 567 | 395 | 319 | 278 | 227 | 165 | | | |
| VEGLIA | | 708 | 399 | 245 | 210 | 175 | 153 | 130 | 75 | 59 | |
| JCB 1707 | 503 | 200 | 105 | 78 | 67 | 59 | 51 | 45 | | | |
| Fitted on Lombardini engine | 927 | 322 | 155 | 112 | 96 | 83 | 71 | 62 | 36 | 29 | |
| Fitted on AIFO engines | | 834 | 436 | 322 | 280 | 243 | 213 | 187 | 113 | 89 | |




| | 0 BAR | 1 BAR | 2 BAR | 3 BAR | 4 BAR | 5 BAR | 6 BAR | 7 BAR | 8 BAR | 9 BAR | OHM |
|-----------------------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|
| TPO/403 | 270 | 251 | 203 | 157 | 114 | 79 | 52 | | | | |
| VDO | 10 | 50 | 85 | 119 | 152 | | | | | | |
| VDO 29/10 | 9 | 38 | 57 | 77 | 99 | 114 | 134 | 149 | 164 | 180 | |
| Fitted on Lombardini engine | 10 | 31 | 52 | 71 | 90 | 107 | 124 | 140 | 156 | 170 | |



TEMPERATURE AND PRESSURE TRANSMITTERS (PROBES) VALUES OHM PROGRAMMING

The control unit is set in the factory for pressure and temperature transmitters type TPO/403 (Pressure) and TTAO/403 (Temperature).
 A max. of 10 resistive values can be set corresponding to the characteristic curves of other pressure and temperature transmitters.

PROGRAMMING OF CORRESPONDENCE



PROGRAMMING



CAUTION: it is necessary to programme at least two values (For precision in temperature and pressure control we recommend programming at least 4 values).
 When programming just one value or non monotonic values, the fault is detected.




OIL TEMP. TABLE NOT CORRECT

or

OIL PRESS. TABLE NOT CORRECT"

SWITCHING OFF AND ON PROCEDURE OF INSTRUMENTS AND FUNCTIONS

Instruments and functions can be switched off and engaged by following the procedures given below.



INSTRUMENTS SWITCHING OFF

(See procedure over)

CAN Bus INSTRUMENTS SWITCHING OFF

| Measurements produced by the DCA-120 control unit | FACTORY PROGRAMMING | | | CAN Bus INSTRUMENTS SWITCHING OFF | | Measurements produced by the control unit of the engine (CAN Bus) |
|---|---------------------|-----|--|-----------------------------------|-----|---|
| | ENGAGED | OFF | | ENGAGED | OFF | |
| TACHOMETER | ● | | | ● | | FUEL USED |
| THERMOMETER INCLUDES/EXCLUDES also the measurement produced by the engine control unit (CAN Bus) | ● | | | ● | | INSTANT. CONSUMPTION |
| OIL PRESSURE GAUGE INCLUDES/EXCLUDES also the measurement produced by the engine control unit (CAN Bus) | ● | | | ● | | FUEL TEMPERATURE |
| | | | | ● | | TURBOCHARGER TEMPERATURE |
| | | | | ● | | OIL TEMPERATURE |
| | | | | ● | | INTERCOOLER TEMPERATURE |
| | | | | ● | | INTAKE TEMPERATURE |
| | | | | ● | | COOLING LIQUID LEVEL |
| | | | | ● | | FUEL PRESSURE |
| | | | | ● | | COOLING LIQUID PRESSURE |
| | | | | | ● | ENGINE TORQUE |
| | | | | ● | | ENGINE LOAD |
| | | | | | ● | ENGINE POWER |
| | | | | ● | | ENGINE IGNITION VIA CANBUS Only for engines featuring this control |
| | | | | | ● | SPEED SETUP Only for engines featuring this control |

FUNCTIONS SWITCHING OFF (see procedure in the preceding page)

| | ENGAGED | OFF |
|---|---|-----|
| MAN MODE (MANUAL) | ● | |
| AUT MODE (AUTOMATIC) | ● | |
| OFF MODE (STOP) | ● | |
| BATTERY UNDERVOLTAGE | ● | |
| BATTERY OVERVOLTAGE | ● | |
| SWITCHING OFF NOT VALID ON CAN Bus ACTIVE | OVERHEATING WARNING | ● |
| | ENGINE OVERHEATING (Sensed by the temperature transmitter) | ● |
| | LOW OIL PRESSURE WARNING | ● |
| STOPPING FAILURE | ● | |
| RPM CONTROL IN AUTOMATIC MODE. (automatic control of working speed) with this function excluded, engine heating and cooling are not carried out. | | ● |
| ENGINE SPEED 1-2 See description in the instructions and user manual. | | ● |
| EMERGENCY STOP STANDBY When enabled, it switches to standby even if the emergency stop button has been pressed. | | ● |
| REMOTE HARE AND REMOTE TORTOISE | | ● |
| STARTING WITH FLAT BATTERY | | ● |
| STAND BY | ● | |
| PICK-UP INTERRUPTED | | ● |
| SMS SENDING EVERY START AND STOP – An SMS message is sent whenever the SMS system is started up or stops automatically | | ● |
| SMS PASSAGE MODE AUT | | ● |
| SMS PASSAGE MODE OFF | | ● |
| SMS RESTORATION OF CYCLICAL MAINTENANCE see description in modem joint (B) | | ● |
| SMS RESET FAULTS | | ● |
| CHARGING ALTERNATOR To exclude this function, also release the selector and carry on the procedure described on page 6. See TACHOMETER ADJUSTMENT with SIGNALS COMING FROM THE PICK-UP MAGNETIC TRANSDUCER. | ● | |
| GENERAL ALARM switching off is possible when this intervenes to warn of the imminent automatic starting except for call starting. It cannot be switched off when the intervention is caused by a fault. | ● | |

CHOICE OF THE PREVIOUSLY PROGRAMMED FUEL FLOAT

FUEL FLOAT CHOICE. The control unit is programmed for a float/rheostat assembly, suitable for the FUEL LEVEL indication.

CHOICE OF FUEL FLOAT

Press to display

| FLOAT | TANK LEVEL | OHM |
|--|------------|-----|
| VEGLIA <small>(factory setting)</small> | FULL | 0 |
| | EMPTY | 300 |
| VDO | FULL | 150 |
| | EMPTY | 0 |
| DATCON | FULL | 37 |
| | EMPTY | 240 |

STOP Press to choose START

VEGLIA

↓

VDO

↓

DATCON

↓

W

↓

PROGRAMM.

To program or change previously programmed values see FUEL FLOAT PROGRAMMING

W

FUEL CONTROL W

Press and wait for PROGRAMMED to be written


It is possible to programme the use of a float with contact that closes to ground in lack of fuel. FUEL CONTROL W

FUEL FLOAT PROGRAMMABLE

PROGRAMMING OF THE OHM VALUES OF THE FUEL FLOAT

It is possible to program 10 resistive values corresponding to the characteristic curves of other floats

PROGRAMMING OF CORRESPONDENCE



50% OHM
--- OHM

STOP START

Decreases Increases

Press to display

CAUTION: it is necessary to programme at least two values (to obtain a good precision in fuel control we recommend programming at least 4 values).
When programming just one value or non-monotonic values, the fault is detected.

INCORRECT FUEL FLOAT TABLE

50%

100 OHM

Hold down and wait for PROGRAMMED to be written

Press briefly to show the carried out programmations


AVAILABLE ANOMALY PROGRAMMING 1÷9

THE NEW DESCRIPTION OF THE ANOMALY IS NOT TRANSLATED

ANOMALY TEXT

HOW TO WRITE

- STOP** - Press to shift the cursor
- START** - Press to write
- Hold pressed until the clearing of one segment keep pressed for the complete clearing




example
1 PARALLEL FAILED

TO INCREASE THE NUMBER OF INPUTS IT IS NECESSARY TO COMBINE EXPANSION MODULE MDE-088 WITH DCA-120/10.

STOP **START**


Press to modify the functions and the intervention delay

NOTE the interventions always activate the general alarm




ANOMALIES HISTORICAL LOG

The data of the last 50 anomalies that have stopped the engine are collected.




SERIAL PORT RS232

SERIAL PORT RS232. MOD BUS - GSM - MODEM - Select GSM 9600 bps to enable connection with the mobile phone and program the three telephone numbers to inform when the engine is in alarm condition.




BOARD ADDRESSES. Addresses can be set for up to 9 boards (control units).




Programming of telephone numbers of the users to inform when the engine is in alarm.

Refer to "Sending SMS messages" in the Modem Manual




CODE FOR RESETING CYCLIC MAINTENANCE: write **006** or **SERVICE** using a mobile phone

BAUDRATE. Select 4800/9600/14400/19200/28800/34400.




SERIAL PORT RS485


CONNECTION: port RS485 can be used to communicate with protocol MOD BUS or the I/O extension.



BOARD ADDRESSES. Addresses can be set for up to 9 boards (control units).



BAUDRATE. Select 4800/9600/14400/19200/28800/34400.



SETUP: N,8,1 or E, 8, 1

