

WORK SHOP MANUAL

RD series engines, p.no. 1-5302-620

RD210
RD211
RD270
RD278

1st Edition



COMPILER TECNICI <i>M. M. M. M. M.</i>	REG. CODE 1-5302-620	MODEL N° 50902	DATE OF ISSUE 08-03	REVISION 00	DATE 01.08.2003	ENDORSED <i>F. M.</i>		1
---	-------------------------	-------------------	------------------------	--------------------	--------------------	--------------------------	---	----------



FOREWORD

We have done all in our power to give up to date and accurate technical information in this manual. Ruggerini engines are, however, constantly developing thus the data in this publication may be liable to modification without prior notice.

The information in this manual is the exclusive property of Ruggerini. Neither partial nor total duplications or reprints are therefore permitted without the express authorization of Ruggerini.

The information in this manual is given on the assumption that:

- 1 - The persons who service Ruggerini engines have been adequately trained and outfitted to safely and professionally carry out the necessary tasks;
- 2 - The persons who service Ruggerini engines possess the necessary skills and special Ruggerini tools to safely and professionally carry out the necessary tasks;
- 3 - The persons who service Ruggerini engines have read the specific information concerning the above mentioned Service operations and that they have clearly understood the operations required.

GENERAL SERVICE NOTES

- 1 - Only use genuine Ruggerini spare parts. Use of spurious spares may lead to incorrect performance and shorten the life of the engines.
- 2 - The metric system is used to express all data, i.e. the dimensions are given in millimeters (mm), torque is expressed in Newton-meters (Nm), weight in kilograms (kg), volume in liters or cubic centimeters (cc) and pressure in barometric units (bar).

2	 COMPILER TECNICATI <i>M. Cimella</i>	REG. CODE 1-5302-620	MODEL N° 50902	DATE OF ISSUE 08-03	REVISION 00	DATE 01.08.2003	ENDORSED <i>[Signature]</i>
---	---	-------------------------	-------------------	------------------------	--------------------	--------------------	--------------------------------

WARRANTY CERTIFICATE

Products Ruggerini Motori manufactured by Lombardini Srl are warranted to be free from non-conformity defects for a period of 24 months from the date of delivery to the first end user.

For engines fitted to stationary equipment, working at constant load and at constant and/or slightly variable speed within the setting limits, the warranty covers a period up to a limit of 2000 working hours, if the above mentioned period (24 months) is not expired.

If no hour-meter is fitted, 12 working hours per calendar day will be considered.

For what concerns the parts subject to wear and deterioration (injection/feeding system, electrical system, cooling system, sealing parts, non-metallic pipes, belts) warranty covers a maximum limit of 2000 working hours, if the above-mentioned period (24 months) is not expired.

For correct maintenance and replacement of these parts, it is necessary to follow the instructions reported in the documentation supplied with each engine.

To ensure the engine warranty is valid, the engine installation, considering the product technical features, must be carried out by qualified personnel only.

The list of the Lombardini authorized dealers for Ruggerini Motori products is reported in the "World Service Organisation" booklet, supplied with each engine.

Special applications involving considerable modifications to the cooling/lubricating system (for ex.: dry oil sump), filtering system, turbo-charged models, will require special written warranty agreements.

Within the above stated periods Lombardini Srl directly or through the Ruggerini Motori authorized network will repair and/or replace free of charge any own part or component that, upon examination by Ruggerini Motori Service Dept. or by an authorized Ruggerini Motori agent, is found to be defective in conformity, workmanship or materials.

Any other responsibility/obligation for different expenses, damages and direct/indirect losses deriving from the engine use or from both the total or partial impossibility of use, is excluded.


The repair or replacement of any component will not extend or renew the warranty period.

Lombardini Srl warranty obligations here above described will be cancelled if:

- Engines are not correctly installed and as a consequence the correct functional parameters are not respected and altered.
- Engines are not used according to the instructions reported in the "Use and Maintenance" booklet supplied with each engine.
- Any seal affixed to the engine by the Manufacturer has been tampered with or removed.
- Spare parts used are not original from Manufacturer.
- Feeding and injection systems are damaged by unauthorized or poor quality fuel types.
- Electrical system failure is due to components, connected to this system, which are not supplied or installed by the Manufacturer.
- Engines have been disassembled, repaired or altered by any part other than an authorized Ruggerini Motori agent.

Following expiration of the above stated warranty periods and working hours, Lombardini will have no further responsibility for warranty and will consider its here above mentioned obligations for warranty complete.

Any warranty request related to non-conformity of the product must be addressed to the Ruggerini Motori service agents.

COMPILER TECNICO 	REG. CODE 1-5302-620	MODEL N° 50902	DATE OF ISSUE 08-03	REVISION 00	DATE 01.08.2003	ENDORSED 		3
--	--------------------------------	--------------------------	-------------------------------	--------------------	---------------------------	--	---	----------

INDEX

This manual contains pertinent information regarding the repair of RUGGERINI air-cooled, indirect injection Diesel engines type **RD210 - RD211, RD270 - RD278**: updated August 01, 2003.

I	TROUBLE SHOOTING	Page	7
II	SAFETY AND WARNING DECALS - SAFETY INSTRUCTIONS	"	8-9
III	MODEL NUMBER AND IDENTIFICATION	"	10
IV	TECHNICAL DATA	"	11
V	CHARACTERISTICS	"	12
VI	OVERALL DIMENSIONS	"	13
VII	SPECIAL TOOLS	"	14
VIII	MAINTENANCE - RECOMMENDED OIL TYPE - REFILLING	"	15-16
IX	DISASSEMBLY OF THE ENGINE	"	17
	Camshaft gear extraction		17
	Crankshaft gear extraction		17
	Flywheel extraction		17
	Oil pressure register valve extraction		17
X	CHECKS AND OVERHAUL	Page	18
	Camshaft		24
	Connecting rods		22
	Crankshaft		23
	Cylinder heads		18
	Cylinders		20
	Governor lever and spring		25
	Oil pump checking		25
	Oil seal rings		24
	Piston rings - Pistons - Piston pins		21
	Rocker arms		20
	Tappet checking		24
	Valves - Guides - Seats		18
	Valves and springs		20

XI	INJECTION EQUIPMENT	Page	26
	Checking injection pump		26
	Fuel circuit		26
	Injection pump		26
	Injection pump assembly		27
	Injection pump setting		26
	Injector checking and setting		28
	Injectors		28
	Testing air tightness		28
XII	ELECTRICAL EQUIPMENT	Page	29
	Alternator checking (stator)		30
	Circuit checking		29
	Electric starting with motor and alternator for battery re-charging		29
	Method of use		30
	Wire checking		30
XIII	ENGINE ASSEMBLY	Page	32
	Camshaft preparation		32
	Checking injector protrusion		38
	Checking start of injection		41
	Checking T.D.C.		40
	Checking valve head face depth		38
	Connecting rod-crankshaft coupling		36
	Crankshaft preparation		33
	Cylinder height adjustement		38
	Cylinder mounting		37
	Feeding pump assembly		36
	Fitting cylinder heads		39
	Fitting of oil seal rings		35
	Injection pump fitting		40
	Injection pump tie rod connection		40
	Oil pump assembly		35
	Piston ring fitting		37
	Piston ring working position		37
	Piston-connection rod couplings		36
	Preparation of crankcase		32
	Protective cap fitting		37
	Timing cover assembly		34
	Upper crankcase preparation		33
	Valve clearance		39

INDEX

XIV	ENGINE TESTING	Page	42
	Checking for oil leaks		42
	Checking oil pressure		42
	Speed adjustment		42
	Testing engine on brake		43
XV	STORAGE	Page	44
	How to prepare the engine for operation		44
	Permanent protection (over 6 months)		44
	Storage		44
	Temporary protection (1/6 months)		44
XVI	QUICK REFERENCE CHARTS	Page	45
	Adjustments		45
	Couplings		45
	End floats		45
	Standard screw tightening torques		46
	Tightening torques		46

POSSIBLE CAUSES AND TROUBLE SHOOTING

The following table contains the possible causes of some failures which may occur during operation. Always perform these simple checks before removing or replacing any part.

POSSIBLE CAUSE		TROUBLE									
		Engine does not start	Engine starts but stops	No acceleration	Non-uniform speed	Black smoke	White smoke	Too low oil pressure	Increase oil level	Excessive oil consumption	Oil and fuel dripping from exhaust
FUEL CIRCUIT	Clogged pipes	•		•							
	Clogged fuel filter	•	•	•			•				
	Air inside fuel circuit	•	•	•	•		•				
	Clogged tank breather hole	•	•	•							
	Faulty fuel pump	•	•								
	Injector jammed	•									
	Jammed injection pump delivery valve	•									
	Wrong injector setting					•				•	
	Excessive plunger blow-by	•				•		•			
	Jammed injection pump delivery control	•		•	•						
Wrong injection pump setting		•	•	•	•						
LUBRICATION	Oil level too high				•		•		•		
	Jammed pressure relief valve							•			
	Worn oil pump							•			
	Air inside oil suction pipe							•			
	Faulty pressure gauge or switch							•			
Clogged oil suction pipe							•				
ELECTRIC SYSTEM	Battery discharged	•									
	Wrong or inefficient cable connection	•									
	Defective ignition switch	•									
	Defective starter motor	•									
MAINTENANCE	Clogged air filter	•		•		•			•		
	Excessive idle operation						•		•	•	
	Incomplete running-in						•		•	•	
	Engine overloaded	•	•	•		•					
SETTINGS/REPAIRS	Advanced injection	•									
	Delayed injection	•				•	•				
	Incorrect governor linkage adjustment	•			•						
	Broken or loose governor spring		•	•							
	Idle speed too low		•		•						
	Worn or jammed piston rings						•		•	•	
	Worn or scored cylinders						•		•	•	
	Worn valve guides						•		•	•	
	Jammed valves	•									
	Worn bearings							•			
	Governor linkage not free to slide	•	•		•						
	Drive shaft not free to slide					•					
Damaged cylinder head gasket	•										


SAFETY AND WARNING DECALS

DANGER



Failure to comply with the instructions could result in damage to persons and property

CAUTION



Failure to comply with the instructions could lead to technical damage to the machine and/or system



SAFETY INSTRUCTIONS

- Ruggenerini Engines are built to supply their performances in a safe and long-lasting way. To obtain these results, it is essential for users to comply with the servicing instructions given in the relative manual along with the safety recommendations listed below.
- The engine has been made according to a machine manufacturer's specifications and all actions required to meet the essential safety and health safeguarding requisites have been taken, as prescribed by the current laws in merit. All uses of the engine beyond those specifically established cannot therefore be considered as conforming to the use defined by Ruggenerini which thus declines all liability for any accidents deriving from such operations.
- The following indications are dedicated to the user of the machine in order to reduce or eliminate risks concerning engine operation in particular, along with the relative routine maintenance work.
- The user must read these instructions carefully and become familiar with the operations described. Failure to do this could lead to serious danger for his personal safety and health and that of any persons who may be in the vicinity of the machine.
- The engine may only be used or assembled on a machine by technicians who are adequately trained about its operation and the deriving dangers. This condition is also essential when it comes to routine and, above all, extraordinary maintenance operations which, in the latter case, must only be carried out by persons specifically trained by Ruggenerini and who work in compliance with the existing documentation.
- Variations to the functional parameters of the engine, adjustments to the fuel flow rate and rotation speed, removal of seals, demounting and refitting of parts not described in the operation and maintenance manual by unauthorized personnel shall relieve Ruggenerini from all and every liability for deriving accidents or for failure to comply with the laws in merit.
- On starting, make sure that the engine is as horizontal as possible, unless the machine specifications differ. In the case of manual start-ups, make sure that the relative actions can take place without the risk of hitting walls or dangerous objects, also considering the movements made by the operator. Pull-starting with a free cord (thus excluding self-winding starting only), is not permitted even in an emergency.
- Make sure that the machine is stable to prevent the risk of overturning.
- Become familiar with how to adjust the rotation speed and stop the engine.
- Never start the engine in a closed place or where there is insufficient ventilation. Combustion creates carbon monoxide, an odourless and highly poisonous gas. Lengthy stays in places where the engine freely exhausts this gas can lead to unconsciousness and death.

8	 COMPILER TECNICI 	REG. CODE 1-5302-620	MODEL N° 50902	DATE OF ISSUE 08-03	REVISION 00	DATE 01.08.2003	ENDORSED 
---	---	-------------------------	-------------------	------------------------	-------------	--------------------	---

MODEL NUMBER

ENGINE IDENTIFICATION


Model

- Engine Serial Number
- Approval code
- Customer's code
- R.P.M. setting
- R.P.M.
- Displacement (cc)

RUGGERINI motori
42100 Reggio Emilia - ITALY

Type RD210
 No. *0000000*
 Omo. DGM 0000/0000 OM
 cc 954 Version X0000
 rpm 3000 rpm setting 3000

trade mark of **LOMBARDINI** made in Italy



CHARACTERISTICS

ENGINE TYPE			RD210	RD211	RD270	RD278	
Number of cylinders			N.	2	2	2	2
Bore			m m	90	90	95	95
Stroke			m m	75	75	85	85
Swept volume			cm ³	954	954	1205	1205
Compression ratio				19:1	19:1	18:1	18:1
Power kW (HP)	N 80/1269/CEE-ISO 1585	@ 3000 RPM	15(20,5)	—	20(27,2)	—	
		@ 3600 RPM	—	17(23)	—	—	
	NB ISO 3046 - 1 IFN	@ 3000 RPM	14(19)	—	18,6(25,3)	9,5(13)#	
		@ 3600 RPM	—	15,7(21,4)	—	—	
	NA ISO 3046 - 1 ICXN	@ 3000 RPM	12,9(17,6)	—	17,2(23,4)	8,6(11,7)#	
		@ 3600 RPM	—	14,5(19,8)	—	—	
Max. torque *			Nm	50@2400	50@2400	66@2200	—
Fuel consumption **			g/kW.h	236	236	245	250
Oil consumption			g/kW.h	0,8	0,8	0,8	0,8
Capacity of standard oil sump			lt	3	3	3	3
Recommended battery 12V			Ah -A	66-300	66-300	90-450	90-450
Dry weight			kg	78	78	96	96
Combustion air volume			m ³ /h	76	90	97	65
Cooling air volume			m ³ /h	800	950	1100	800
Max. permissible driving shaft axial: continuous (instantaneous)			kg.	100(350)	100(350)	100(350)	100(350)
Max. inclination	Flywheel site: continuous (instantaneous)			25°(35°)	25°(35°)	25°(35°)	25°(35°)
	Power take off site: continuous (instantaneous)			25°(40°)	25°(40°)	25°(40°)	25°(40°)
	Lateral: continuous (instantaneous)			25°(40°)	25°(40°)	25°(40°)	25°(40°)


* Referred to N power

** Consumption at max torque


@ 1500 RPM

CHARACTERISTICS POWER, TORQUE AND SPECIFIC FUEL CONSUMPTION CURVES

RD210-211



RD270



N (80/1269/EEC - ISO 1585)

AUTOMOTIVE RATING : Intermittent operation with variable speed and variable load.

NB (ISO 3046 - 1 IFN)

RATING WITH NO OVERLOAD CAPABILITY: continuous light duty operation with constant speed and variable load.

NA (ISO 3046 - 1 ICXN)

CONTINUOUS RATING WITH OVERLOAD CAPABILITY: continuous heavy duty with constant speed and constant load.

Mt-N Torque at N power.

C Specific fuel consumption at N power.

U1: Standard utilization range of engines rated at 3000 rpm

U2: Standard utilization range of engines rated at 3600 rpm

The above power values refer to an engine fitted with air cleaner and standard muffler, after testing and at the environmental conditions of 20°C and 1 bar.

Max. power tolerance is 5%.

Power decreases by approximately 1% every 100 m di altitude and by 2% every 5°C above 25°C.

Note: Consult RUGGERINI for power, torque curves and specific consumptions at rates differing from those given above.

12		COMPILER TECNICI	REG. CODE	MODEL N°	DATE OF ISSUE	REVISION 00	DATE	ENDORSED
		<i>M. Mimella</i>	1-5302-620	50902	08-03	01.08.2003	<i>[Signature]</i>	



Failure to carry out the operations described in the table may lead to technical damage to the machine and/or system

MANUTENANCE

OPERATION	COMPONENT		INTERVAL (HOURS)							
			8	50	200	300	500	2500	5000	
CLEANING	OIL-BATH AIR CLEANER		(*)	●						
	HEAD AND CYLINDER FINS		(*)	●						
	FUEL TANK						●			
	INJECTOR						●			
CHECK	LEVEL	AIR CLEANER OIL		●						
		OIL SUMP		●						
		BATTERY FLUID			●					
	VALVE/ROCKER ARM CLEARANCE						●			
	INJECTOR SETTING						●			
REPLACEMENT	OIL	AIR CLEANER	(**)(***)		□	●				
		SUMP				●				
	EXTERNAL OIL FILTER CARTRIDGE						●			
	FUEL FILTER CARTRIDGE						●			
	DRY AIR CLEANER CARTRIDGE						●			
OVERALL INSPECTION	PARTIAL		(x)							●
	COMPLETE		(xx)							

- First replacement
- (*) Under severe working conditions, clean daily.
- (**) Under extremely dusty conditions, change every 4-5 hours.
- (***) See recommended oil type.
- (x) The partial overhaul includes the following operations: valve and seat lapping, injector and injection pump overhaul, injector projection check, fuel injection spark advance check, check of the harmful area between head and piston, camshaft and crankshaft end float check, tightening of bolts.
- (xx) The general overhaul includes - in addition to all partial overhaul - the following procedures: cylinder and piston replacement, seat, guide and valve refacing, crankshaft replacement or grinding, bench bearing and connecting rod replacement.

The maintenance operations listed above refer to an engine operating in normal conditions (temperature, degree of humidity, dust in the working environment). They may vary significantly according to the type of use.



To avoid explosions or fire outbreaks, do not smoke or use naked flames during the operations. Fuel vapours are highly toxic. Only carry out the operations outdoors or in a well ventilated place. Keep your face well away from the plug to prevent harmful vapours from being inhaled. Dispose of fuel in the correct way and do not litter as it is highly polluting.

FUEL

When refuelling, it is advisable to use a funnel to prevent fuel from spilling out. The fuel should also be filtered to prevent dust or dirt from entering the tank. Use the same type of diesel fuel as used in cars. Use of other types of fuel could damage the engine. The cetane rating of the fuel must be higher than 45 to prevent difficult starting. Do not use dirty diesel fuel or mixtures of diesel fuel and water since this would cause serious engine faults.

The capacity of the standard tank is: lt. 7.0



The engine could be damaged if allowed to operate with insufficient oil. It is also dangerous to add too much oil as its combustion could sharply increase the rotation speed.

Use a suitable oil in order to protect the engine.

The lubrication oil influences the performances and life of the engine in an incredible way.

The risk of piston seizure, jammed piston rings and rapid wear of the cylinder liner, the bearings and all moving parts increases if oil whose characteristics differ from the recommended type is used, or if the oil is not regularly changed. All this notably reduces engine life.

Oil viscosity must suit the ambient temperature in which the engine operates.



Old oil can cause skin cancer if repeatedly left in contact with the skin and for long periods of time. If contact with the oil is inevitable, you are advised to thoroughly wash your hands with soap and water as soon as possible.

Appropriate protective gloves etc should be wore during this operation.

Old oil is highly polluting and must be disposed of in the correct way. Do not litter.

RECOMMENDED OIL

AGIP SINT 2000 5W40 specification API SJ/CF ACEA A3-96 B3-96 MIL-L-46152 D/E.

ESSO ULTRA 10W40 specification API SJ/CF ACEA A3-96 MIL-L-46152 D/E.


In countries where AGIP and ESSO products are not available, use API SJ/CF oil for gasoline-fuelled engines or oil that complies with military specification MIL-L-46152 D/E.

OIL SUPPLY (liters)

Standard oil sump

filter included 3.0 l.

GRADE




ACEA SEQUENCES

- A = Gasoline (Petrol)
- B = Light Diesel fuels
- E = Heavy Diesel fuels

Required levels :

- A1-96
- A2-96
- A3-96
- B1-96
- B2-96
- B3-96
- E1-96
- E2-96
- E3-96

DIESEL							BENZINA - ESSENCE - PETROL BENZIN - GASOLINA										
API	CF	CE	CD	CC	CB	CA	SA	SB	SC	SD	SE	SF	SG	SH	SJ		
							CCMC G-2					G-4					
							CCMC G-3					G-5					
							CCMC PD - 1 / PD - 2										
			D-4	CCMC D-2													
	D-5	CCMC D-3															
				MIL - L - 2104 D													
				MIL - L - 2104 E													
				MIL - L - 46152 C													
				MIL - L - 46152 D/E													
				MB 226.1								MB 226.5					
				MB 227.1								MB 227.5					
	228.3	MB 228.1															
				VW 500.00													
				VW 501.01													
				VW 505.00													
				VOLVO VDS													
				MAN QC 13-017													




1



During repair operations, when using compressed air, wear eye protection.

DISASSEMBLY AND REASSEMBLY

Besides disassembly and reassembly operations this chapter also includes checking and setting specifications, dimensions, repair and operating instructions. Always use original RUGGERINI spare parts for repair operations.



2

Flywheel extraction

Use extractor cod. **00365R0020**, as shown in figure 1.




During the demounting phases, pay particular attention to prevent the flywheel from dropping as this could seriously injure the operator.

Wear protective goggles when removing the flywheel ring.



IMPORTANT: Do not tap the end of the extractor when removing the flywheel.




3

Crankshaft gear extraction

Use extractor cod. **00365R0010** and cod. **00365R0100** (fig. 2).

Camshaft gear extraction


Use extractor cod. **00365R0010** (fig. 3).



4

Oil pressure register valve extraction

Use extractor cod. **00365R0880** (fig. 4).



Cylinder heads

Details of fig. 5:


1. Cylinder head - 2. Pipe - 3. O-Ring - 4. Rockerarms - 5. Rockers - 6. Cotters - 7. Plates - 8. Springs - 9. Guides - 10. Seats - 11. Valves - 12. Tappets - 13. Camshaft.

The heads are of aluminium with inserted guides and valve seats in cast iron. Make sure there are no cracks or imperfections. Should it be so, replace according to the instructions given in the spare parts catalogue.



Never remove head while still hot in order to avoid deformation.

5



Valves - Guides - Seats

Clean the valves with a wire brush and renew them if the valve heads are deformed, cracked or worn.


Check clearance between valve and guide with a micrometer on stem B (fig. 7) and with a go/no go gauge as shown in fig. 6 (tool cod. **00365R0450, 00365R0400, 00365R0410**).

Change the guide if the maximum gauge diameter passes through it, as it has passed the maximum permissible wear.

After having fitted the new guide, check exact diameter using the "go" end of the gauge and if necessary grind it to the dimensions indicated in the table using the adjustable grinder (tool cod. **00365R0850, 00365R0860**).

6

Engine	Guide	Ø Guide mm	Ø Gauge mm	
			go	no go
RD210	Inlet	7,000 ÷ 7,010	7,000	7,079
RD211	Outlet			
RD270	Inlet	9,020 ÷ 9,030	9,020	9,100
RD278	Outlet			



7


Fitting of new guides always requires grinding of the valve seats (see page 19).

Valve guides with an external diameter increased by **0.10 mm** are available.

If the inlet clearance between valve and guide is lower than **0.08 mm** and the outlet clearance is lower than, **0.10 mm**, the wear on **B** is less than **0.03 mm** and **A** is more than **0.05 mm**, recondition the valve by grinding face **P** to **45°** (fig. 7).


As a result of prolonged engine operation, the hammering of the valves on their seats at high temperature causes the face of the seats to harden and hand grinding is made difficult. It is thus necessary to remove the hardened surface with a **45°** cutter mounted on a valve seat grinding tool (fig. 8). Final fitting can then be carried out manually with the cutters listed below.

Cut dimensions for valve seats



8

Engine	Inlet		Outlet	
	A x B	Ø guide	A x B	Ø guide
RD210	40 x 12 mm	7 mm	38 x 12 mm	7 mm
RD211				
RD270	38 x 12 mm	9 mm	38 x 12 mm	9 mm
RD278				



9


Cutting of the valve seats involves the widening of the valve seat face **P** with a consequent reduction of seal of the valve itself, fig. 9

If face **P** is more than **2 mm** wide, invert cutter and lower level **Q** of the seat, fig. 10, so as to restore the **P** level to the value of:

Fitting mm	Max. wear mm
0,7 ÷ 1,2	2

Final lapping of the valve on the seat must be carried out by coating the seat with a fire grinding paste and rotating the valve backwards and forwards with a slight pressure until a perfect finish to the surface is obtained (fig. 11).

Make sure the face of the valve head in relation to the face of the cylinder head is:




10

Fitting mm	Max. wear mm
0,9 ÷ 1,1	1,8



If the distance is less, the valve will strike the piston.
If the distance is more than **1.8 mm** the valve seat rings need to be changed. Fitting of new valves or seats always requires grinding.

Valve seats with an external diameter increased by **0.2 mm** for the RD210 and **0.5 mm** for the RD270, are available.



11


After grinding, wash valve and seat carefully with petrol or paraffin to eliminate any residual grinding paste or cuttings.

To check the worthiness of the seal between valve and seat, after grinding has taken place, proceed as follows:


1. Fit valve on head with spring, plates and cotters (see fig. 5).
2. Invert head and pour a few drops of diesel or oil round the outside of the valve head.
3. Blow compressed air into the inlet of the cylinder head, taking care to seal the edges so that the air does not escape (fig. 12).

Should air bubbles form between the seat and the valve, remove the valve and regrind the seat.

The fit can also be checked by pushing the valve upwards and letting it fall freely down onto its seat. If the resulting bounce is considerable and uniform, also when the valve is rotated, it means that the fit is good. If not, continue grinding until the conditions described above are achieved.



12




17

Piston rings - Pistons - Piston pins

Check the wear of piston rings by fitting them into the cylinder through the lower end and measuring the end gap (fig.17). The values should be:

Piston ring	Fitting mm	Max. wear mm
Compression	0,30 ÷ 0,50	0,80
Oil scrapper	0,25 ÷ 0,50	0,80



18


Check that the rings move freely in the grooves and check the ring/groove clearance using a feeler gauge (fig.18).

If the clearance exceeds the values shown in the table, renew the piston and the piston rings.

Piston ring	Max. wear mm
1st Compression	A = 0,22
2nd- 3rd Compression	B - C = 0,18
4th Oil scrapper	D = 0,16



Piston rings must always be renewed after dismantling the piston.



19


Piston diameter check: The diameter of the piston must be measured at approximately 18 mm from the base (fig.19).

Engine	Diameter mm
RD210 RD 211	89,919 ÷ 89,930
RD270 RD278	94,920 ÷ 94,935

Check the clearance between cylinder and piston, if it is greater than 0.120 mm both cylinder and piston must be replaced.

Assembly clearance between piston pin and piston in millimetres:

Fitting mm	Max. wear mm
0,001 ÷ 0,010	0,060




23

Crankshaft

Whenever the engine is dismantled, particularly for the replacement of cylinders and pistons due to wear caused by the aspiration of dust, it is good practice to check the condition of the crankshaft.

1. Remove the plugs "A" from the oil passages (fig.23).
2. Use an appropriately shaped steel punch to clean the inside of the oil passages and the collection traps. If the deposits are particularly resistant, immerse the whole crankshaft in petrol or paraffin before proceeding with the operations.
3. When the oil passages and traps have been thoroughly cleaned, close the openings with new plugs (fig.24).




24

Checking crankshaft dimensions

Once the crankshaft has been thoroughly cleaned, use a micrometer to check the wear and ovality of the main journals and crank journals across two sections at right angles to each other (fig.25).

If wear exceeds 0.08 mm (fig.26) grind the crankshaft to the dimensions shown in the table:


Dimensions	STD mm	-0,25 mm	-0,50 mm
A	45,005 ÷ 45,015	44,755 ÷ 44,765	44,505 ÷ 44,515
B	44,994 ÷ 45,010	44,744 ÷ 44,760	44,494 ÷ 44,510



25

Undersize bearing bushes are already available at the necessary sizes without requiring any adjustment by boring.


Main bearing bushes with increased external diameters are also available. Table indicates the crankcase boring values.



26

Bearing	Ø of brush housingmm
Standard	47,965 ÷ 47,985
+ 1 mm	48,965 ÷ 48,985

! During grinding take care not to remove the shim adjustment material from the main journal thrust face to avoid changing the crankshaft end float; also ensure that the grinding wheel radii are as specified in figure 26 so as not to create crack initiation sections on the crankshaft.




27

Camshaft

Check cams and support pins for wear or scores. Check amount of wear by measuring points **A** and **B** shown in fig. 27 and 28 and comparing to the figures of the tables hereunder:

Distribution cam dimensions (fig. 27).

Engine	Measurement	Fitting mm	Max. wear mm
RD210-211	A-B	29,95 ÷ 30,00	29,70
RD270-278	A-B	30,52 ÷ 30,57	30,25



28

Injection cam dimensions (fig. 28)

Engine	Measurement	Fitting mm	Max. wear mm
RD210-211-270-278	A	28,39 ÷ 28,43	28,30

The coupling clearance between pins and respective housings should be:

Fitting mm	Max. wear mm
0,015 ÷ 0,048	0,100




Renew the camshaft if the cams or journals show wear in excess of 0.1mm.

Oil seal rings

Make sure the oil seals have not hardened round the internal contact edge with the crankshaft and that they do not show signs of cracks or wear. If they do, replace them with new ones of the same size.



Then re-fitting the oil seal, use protective cone cod. **00365R0260**. Fit said cone over the ends of the crankshaft to avoid damage to the ring itself.




29

Tappet checking

Make sure the tappet surfaces are not worn, lined or present signs of seizure. If so, replace.

Tappet and seat check in mm (fig. 29).

Measurement	Fitting mm	Max. assy. clearance mm
Tappet	11,98 ÷ 11,99	0,10
Tappet seat	12,00 ÷ 12,018	




30

Governor lever and spring

Check that the shoes (**S**, fig. 30) are level and that the springs have not lost their elasticity. Renew any excessively worn parts after consulting the spare parts catalogue.

Supplement and governor spring dimensions (fig. 30):

Spring	Lenght mm	Lenght under load mm	Load kg	Nr of windings
Supplement (H)	16,9 ÷ 17,4	35	0,3	18,5
Governor (N)	53	69,2	2,5	13




31

Oil pump checking

The pump is of the lobed rotor type driven by the camshaft. Dismantle pump and check rotors. Check lobes and centers and if they are worn, replace rotors. Check the amount of pump wear, measure rotor **A** and rotor **B** (see fig. 31), and compare to the following table:

Measurement	Dimensions mm	Max. wear mm
C	29,745 ÷ 29,770	29,700
D	40,551 ÷ 40,576	40,45
E	30,030 ÷ 30,60	30,10
F	17,920 ÷ 17,940	17,89



32


If wear exceed these figures, replace complete pump.

The coupling clearance between oil pump external rotor and basement housing is:

Fitting mm	Max. wear mm
0,094 ÷ 0,144	0,294

The axial clearance of the rotors (fig. 32) should be between:

Fitting mm	Max. wear mm
0,010 ÷ 0,050	0,100




RD210 RD 211

Fuel circuit

Feeding is carried out by a diaphragm pump actuated by a camshaft eccentric coupled to a cap. See assembly on page 36 and consult spare parts catalogue for replacement.

Details of fig. 33:

- 1.Tank - 2.Diesel filter - 3.Feeding pump - 4.Injection pump - 5.Injection pipes - 6.Injectors - 7.Diesel discharge pipe.



RD270 RD278

Injection pump

The injection pump is of the single casing type with two, constant stroke, separate pumping elements. Details of fig. 34.


- 1.Pump casing - 2.Pumping element - 3.Rack bar - 4.Eccentric dowel - 5.Adjusting bushing - 6.Spring - 7.Lower plate - 8.Tappet - 9.Upper plate - 10.Locking pin - 11.13.18.Gaskets - 12.Diesel intake connection - 14.Diesel exhaust screw - 15.Delivery valve -16.O-ring - 17.Valve spring - 19.Delivery connection.

Checking injection pump

Before dismantling injection pump check pressure seal of the pumping unit, cylinder and valve as follows:

- 1.Connect a pressure gauge graded up to **600 kg/cm²** (fig. 35) to the diesel delivery pipe.
- 2.Set the rack bar in a half way position.
- 3.Rotate flywheel slowly until the pumping element has completed a compression stroke.

33




34



If the test is carried out on the bench, take care that the pumping element does not strike the delivery valve while pumping.


- 4.Take the pressure gauge reading. If the reading is less than **300 kg/cm²**, the complete pumping unit must be replaced. During the test, the reading on the gauge will show a progressive pressure increase to a maximum value and will then fall suddenly and stop at a lower pressure. Replace valve if the fall in pressure exceeds **50 kg/cm²** and continues to fall slowly.



35

Injection pump setting


Register eccentric dowel to the maximum capacity of the pumping elements (q, fig. 39).



36

The quantity of diesel is in relation to 1000 deliveries with the rack bar at **8 mm** from the stop position.

Engine	Ø Pumping element mm	cc valve	Valve Ø mm	Capacity cc	Pump RPM
RD210-211	6	15	4	24 ÷ 26	1500
RD270	7	25	5	31 ÷ 33	1500
RD278	8	25	5	41 ÷ 43	1500




37

Injection pump assembly

After having dismantled the injection pump it should be reassembled in the following manner:

1. Insert cylinders into pump casing with diesel inlet opposite to feeding inlet connection (fig. 36). This position is necessary due to two eccentric dowels on the pump casing. Make sure the supporting faces of the cylinders and pumps are free of dirt.
2. Fix cylinders by inserting valves and temporarily tightening the delivery connections to stop the pumping elements from coming out. (fig. 37).
3. Insert rack bar and lock in a half way position (fig. 38). Make sure the bar moves freely on the guides. Resistance and drag will cause the engine to run unevenly.
4. Marks **b** cut on the bar must coincide with marks **a** of the toothed quadrants. Marks **c** on toothed quadrants must coincide with marks **d** on the flanges of the piston (fig. 39).
5. Insert piston into cylinder with groove turned towards the eccentric dowel on the pump casing.
6. Complete assembly of pump.




38


IMPORTANT: The roller tappets (No 8 fig. 34) and the lower plates are not interchangeable as they determine the timing of the pumping elements.

When replacing parts make sure that:

- a. the distance between the injection cam in bottom dead centre position (PMI) and the pump supporting surface is **82.6 to 83 mm** as stated on the plate.
 - b. the piston stroke from the bottom dead centre position (PMI) of the injection cam to delivery commencement is **2.0 to 2.1 mm** for Ø 6 and 7 mm pumping elements and **2.2 to 2.3 mm** for Ø 8 mm pumping elements.
7. Check pressure seal again, as described in paragraph "Checking injection pump" page 26, to make sure the replaced parts are working properly.



39




40

Testing air tightness

Feed pressurized air at 6 kg/cm² into the fuel sully union and completely immerse the pump in oil or diesel fuel for about 20 ÷ 30 seconds (fig.40); check that no air bubbles are released.

N.B.: Tightness can be checked by compressing the springs to 52.8 ÷ 54.4 mm, which corresponds to the bottom dead centre working position of the pump.



41

Injectors (fig. 41)


The engines can be equipped with three different types of injectors.

Type A injector for RD 210-211

1.Body - 2.Nozzle - 3.Ring nut - 4.Plate - 5.Rod - 6.Spring - 7.Adjustment shim.

Type B injector for RD 270-278

1.Body - 2.Nozzle - 3.Ring nut - 4.Plate - 5.Rod - 6.Spring - 7.Adjustment shim.



42

Injector checking and setting

1. Clean out nozzle holes with a thin piece of wire (fig. 42) of the same size as that of the nozzle holes indicated on the table:

Engine	Ø holes mm
RD210 RD 211	0,25
RD270 RD278	0,28

2. Set up injector on a test bench (tool cod. 00365R0430).


3. Unscrew injector lock coupling (No 3 fig. 41) or nozzle ring nut and insert adjustment shim (7, fig. 41) until the pressure indicated in the table hereunder is reached on the pressure gauge while pumping.

Engine	Setting kg/cm ²
RD210 RD 211	225 ÷ 235
RD270 RD278	220 ÷ 230

4. Tighten the nozzle ring nut (No 3 fig. 41) at:

5 kgm (49 Nm)

5. When setting is complete, while still at the test bench, run pumping elements a few times and check the amount of diesel that passes through the upper leak-off of the injector (fig. 43).



43

Electric starting with motor and alternator for battery re-charging

Characteristics:

Starter motor: anticlockwise rotation.

12V - 1.5 HP (1.1 kW) for RD 210-211

12V - 2.5 HP (1.9 kW) for RD 270-278

12V - 3.4 HP (2.5 kW) for RD 270-278

Flywheel alternator:

- For re-charging **12V/280W** batteries giving 17A charge at **3000 RPM**, for RD 210-211

- For re-charging **12V/220W** batteries giving 14A charge at **3000 RPM**, for RD 270-278

Regulator:

Electronic with controlled diodes and preset for battery re-charging pilot light connection.

12V/24A for RD 210-211

12V/18A for RD 270-278

Optional external alternator with belt control:

- **RD 210-211** for re-charging **12V/200W** batteries giving **15.5A** charge at **6000 RPM** with **12V/26A** voltage adjustor.

- **RD 270-278** for re-charging **12V/400W** batteries giving **30A** charge at **8000 RPM** with built-in voltage adjustor.

Battery:

12V; 80 to 90 Ah

To check starting system circuit see figures 47.

Circuit checking

1. Make sure the connections between regulator and alternator are correct and in good condition.
2. Detach from the terminal on the starter motor, the red wire coming from the alternator, and insert a direct current ammeter with a **20 Amp** range between said free terminal and the detached wire.
3. Connect a direct current voltmeter with a minimum range of **15 Volts** (fig. 44), to the battery terminals.
4. Insert starter key and start up a few times at no load or insert a lamp load of **80 to 100 W** at the ends of the battery to keep the battery voltage under **13 Volts**.
5. Run the engine up to the maximum of **3000 RPM**. The charging current reading on the ammeter should be about:

17A with **12V/280W** alternator

14A with **12V/210W** alternator


For intermediate values see fig. 46.


6. Disconnect lamp load and keep engine running at A/m revs. for some time.

The battery voltage will increase progressively until it reaches the setting limit of the regulator which is about **14.5 V**.

Simultaneously, the charging current will drop to about **2A**. This will occur very quickly if the battery is charged and slowly if it is discharged.

7. If the charging current cuts out or is lower than the values given above, replace governor. If the performance does not improve after this replacement, the trouble must be locked for in the alternator.






45

Alternator checking (stator)

Disconnect alternator cables from the regulator and check continuity between the windings with an Ohmmeter. Also check that there is good insulation between cables and earth (fig. 45). In the event of an open circuit, replace the stator. If the stator is in good working order but the values of the alternator charge are lower than those stated, the rotor is demagnetised and the entire alternator must be replaced.





46

Wire checking



Examine condition of wires bearing the following in mind:

1. With one of the yellow wires open circuited, the alternator will not supply current for the 12V/280W and will only supply half current for the 12V/210W.
2. With both yellow wires open circuited, the alternator will not supply current at all.
3. With one or both wires earthed, the rotor will demagnetize very quickly and the coils of the stator will burn out.
4. With red wire open circuited, the alternator will not supply current.
5. With red wire earthed the alternator will not supply current, the connection wires and warning circuit will burn out and the battery will discharge completely.
6. Avoid sparks between cables, as the alternator could burn out.
7. With an imperfect earth between the negative battery terminal and regulator casing, the charging current is irregular and the regulator could be damaged.
8. If the battery connections are inverted, the alternator and regulator will burn immediately.



47

Method of use

By turning the starter key to the first position, the battery charging circuit is started off, and thus:

1. With engine stationary the key must be kept on the off position. If it is left on the first position, the oil warning light could burn out, the battery could discharge and the regulator could be damaged.
2. With engine running turn key to first position. If it is left in the off position, the oil warning light and battery charging functions are excluded.



The voltage regulator will be damaged beyond repair, if it is run with the battery cables disconnected or with unactivated batteries.




Diagram of electric starting wiring system with flywheel alternator (fig. 47).

1. Battery - 2. Regulator - 3. Alternator - 4. Starter motor - 5. Pressure gauge - 6. Oil pressure warning light - 7. Starter key - 8. Battery charging light.


Diagram of electric starting wiring system with external alternator (fig. 48).

Alternator 12V/200W:

1. Battery - 2. Regulator - 3. Alternator - 4. Starter motor - 5. Pressure gauge - 6. Oil pressure warning light - 7. Starter key - 8. Battery charging light.

Alternator 12V/400W:


1. Battery - 2. Alternator - 3. Starter motor - 4. Starter key - 5. Oil pressure light and battery charging warning light - 6. Pressure gauge.



53

Crankshaft preparation


The insertion of the main distribution gear onto the crankshaft must be carried out while hot. Heat by means of dry heating or an oil bath at 70/80 °C (fig. 53).



54

Upper crankcase preparation


1. Insert accelerator internal lever onto crankcase taking care not to damage the oil seal O-Ring.
2. Fit interchangeable tappets into housings on crankcase.
3. Camshaft assembly (fig. 54): in order to assemble the shaft correctly, the cams must be introduced, without applying force, along the grooves inside the crankcase.
4. Mount governor lever and insert lever fulcrum pin taking care not to damage the oil seal rings (fig. 55). The lever should be able to effect the complete stroke without strain. Insert spring between governor lever and accelerator.
5. Insert main bearings into respective housings and spread with oil slightly. The three main bearings are identical and interchangeable.
6. Fit rubber gaskets and O-Rings between crankcases taking care to insert same properly into respective grooves so as to prevent oil leaks between the contact surfaces (fig. 56).




55



It is advisable to spread a bit of rubber adhesive round the edges of the rubber gasket for better seal.



56



57

7. Place crankshaft on previously housed shells making sure the timing references found on the gears coincide (fig. 57).

8. Insert oil seal rings on the drive side of the crankshaft (fig. 58).




A warped oil retainer may allow the introduction of air into the engine thus causing crankcase ventilation problems. Use genuine oil retainers with the RUGGERINI.

9. Mount lower crankcase complete with studs, centering pins and bearings.

10. Take care to insert the centering pins between crankcases into their respective housings without using force.

11. Tighten crankcase screws, to starting from the centre and alternating towards the outside at:

kgm 1,3 (Nm 12,8)



58

Timing cover assembly

Before mounting the timing cover check that between the gear shims and the crankcase surface (fig. 59) there is a maxi clearance of:


0,10 mm

The axial clearance is measured at the timing cover gaskets and must be between:


0,10 ÷ 0,20 mm

If the axial clearance of the crankshaft becomes excessive after a long working period, add adjustment shims to the engine shaft and camshaft gear until the clearance returns to normal values (fig. 60).


0.2 and 0.3 mm shims are available.



59



60




61

Fitting of oil seal rings

To introduce oil seal ring, flywheel side, use an ordinary cylindrical plug of appropriate size as shown in fig. 61.




A warped oil retainer may allow the introduction of air into the engine thus causing crankcase ventilation problems. Use genuine oil retainers with the RUGGERINI. The oil seal rings are to be fitted with the arrow pointing in the same direction of the crankshaft rotation.



62

Final insertion of the oil seal ring, drive side, requires the use of special tool code **00365R0040** (fig. 62).



63


Oil pump assembly

For rotor checks see page 25.

After tightening crankcase, mount oil pump external rotor with the notch facing inwards (fig. 63).

Make sure the O-Ring on the oil pump cover is in perfect condition. Tighten screws gradually to a pressure of:

kgm 1 (Nm 9,8)



Piston ring fitting

Fit rings onto pistons in the following order (fig. 68):


RD210-211

1. Chromed compression seal ring.
2. Torsional compression seal ring (with internal notch turned upwards).
3. Expander oil scraper ring.

RD270-278

1. Chromed compression seal ring.
2. Torsional compression seal ring (with internal notch turned upwards);
3. Torsional compression seal ring with external step turned downwards.
4. Expander oil scraper ring.

68



Piston ring working position


RD210-211

Before mounting cylinders, rotate rings 120° opposite to each other with the ends of the 1st compression ring in line with the gudgeon pin axis.

RD270-278

Before mounting the cylinders, rotate rings (fig. 69) as follows:
 First and third with the ends rotated at 15° in relation with the gudgeon pin axis.
 Second and fourth with their ends at 180° from the ones above.

69



Protective cap fitting

To prevent the entrance of dust and water which could block the cylinder studs to the upper crankcase, insert protective caps on the studs themselves (fig. 70).

To facilitate cap mounting, oil stud roots.

Insert on crankcase, under the rocker shaft pipes, plates for the lubrication of the camshaft.

70




Cylinder mounting

The lower end of the cylinder is chamfered for piston ring insertion (fig. 71).

The operation can be carried out easily by using a standard piston ring compression tool (tool **00365R0770** and cod. **00365R0800**).

71

**Cylinder height adjustment**


Between the top face of the cylinder and the piston at top dead center, there must be a clearance of:

0,25 ÷ 0,35 mm



In order to carry out this operation correctly, make the check with the cylinder pressed well down on its crankcase (fig. 72).


72



The clearance is adjusted by means of shims inserted between the lower face of the cylinder and crankcase (fig. 73).

Shim dimensions: **0.1 to 0.2 mm**

73


**Checking valve head face depth**

When replacing valves check that the clearance from the top of the head to the face (fig. 74) is of:

Fitting mm	Max. wear mm
0,9 ÷ 1,1	1,8

For different values see on pages 18-19.

74


**Checking injector protrusion**

Before mounting the heads on the cylinders, insert injectors in their housings and after having secured them temporarily, check protrusion of nozzles from head surface (fig. 75).

Protusion **S** should be:


Engine	mm
RD210 RD 211	2,25 ÷ 2,75
RD270 RD278	3,75 ÷ 4,25

75



76

Adjustment is effected by inserting copper washers between the injector and injector supporting faces on the heads (fig. 76). Washer thickness **1 mm** (RD210-211) and **0.5 mm** (RD270-278).




77

Fitting cylinder heads

Insert oil seal O-rings on rocker arm housing and fit the cylinder head in place. Insert 0.5 mm copper gaskets between the surfaces. (fig. 77).



Make sure the oil seal rings are housed properly in the heads to avoid oil leaks.



78

Align heads using a manifold or a metallic bar as shown in fig. 78. Tighten down cylinder head nuts uniformly (fig. 78) increasing 1 kgm at every turn until a pressure is reached of:

5 kgm (49 Nm)




79

Valve clearance

The clearance between valves and rockers with the engine cold (fig. 79) is:

**0,15 mm
intake/exhaust**

The operation must be carried out with the pistons at their top dead center compression position.



84

Checking start of injection


1. Connect fuel tank to injection pump.
2. Bring accelerator lever to max. position and piston, flywheel side, at compression beginning (cylinder No 1)

! All operations are to be carried out with the rack bar in working position to annul the delay caused by the notch on the pumping element of the injection pump.

3. Fit the special tool, p.n. **00365R0940**, to the delivery valve holder (flywheel side) as shown in figure 84.

4. Insert a band (fig. 85) to ease the tension of the spring.

5. Turn the flywheel slowly until the column of diesel fuel inside the special tool starts to move. This indicates the start of static injection.



85


At this moment injection pump delivery starts (fig. 86) and the top dead centre reference on the air conveyor must coincide with the **IP** mark punched on the flywheel (fig. 87).

If the **IP** mark falls short of the notch on the air conveyor, injection is too fast. The injection pump must be disassembled and shims must be added between the pump flange and the crank-case.

If the **IP** mark falls after the T.D.C. reference notch, injection is too slow and the above operation is to be inverted.


Bear in mind that every **0.1 mm** shim under the pump corresponds to a **2.5 mm** rotation of the flywheel.

Repeat operation on second pumping element.




86

Should the flywheel need to be replaced, the top dead center compression position of the pistons is to be determined as per page 40 and the start of injection according to the following table:



87

Engine	I.P.	Ø flywheel
RD210-211	26° = 53,5 mm	236mm
RD270	27° = 67 mm	285mm
RD278	22° = 54,5 mm	285mm




92

Testing engine on brake

After having placed the engine on the brake (fig. 92), proceed with the following operations:

1. Check oil level (fig. 93).
2. Start engine and run at minimum speed.
3. Check oil pressure on pressure gauge (fig. 90).
4. Run engine in before testing it at full power.




93

Running-in table

Time (min)	RPM	Load
5	2000	0
15	3000/3600	0
30	3000/3600	30%
30	3000/3600	50%
30	3000/3600	70%
5	3000/3600	100%

Engine power curves are reported at page 12.



94



In order to check that the setting is correct, without tools, accelerate the engine a few times with no load and check the exhaust fumes.

Delivery of diesel fuel is correctly calibrated when the exhaust gas is slightly coloured by smoke; change the adjustment if necessary by turning the adjustment screw (fig. 94).

Couplings	Spiel (mm)	Grezen (mm)
Camshaft journal and housing in timing cover	0,017 ÷ 0,047	0,1
Camshaft journal and housing in crankcase	0,015 ÷ 0,048	0,1
End gap of compression rings	0,30 ÷ 0,50	0,8
End gap of oil scraper rings	0,25 ÷ 0,40	0,7
Connecting rod and wrist pin RD210-211	0,023 ÷ 0,038	0,07
Connecting rod and wrist pin RD270-278	0,001 ÷ 0,007	0,05
Rockers and shaft	0,030 ÷ 0,056	0,15
Main journals and bearings bushes	0,010 ÷ 0,060	0,15
Oil pump drive gear spindle and housing in crankcase	0,030 ÷ 0,065	0,115
External oil pump rotor and housing in engine crankcase	0,094 ÷ 0,144	0,294
Pistons and wrist pin RD210-211	0,002 ÷ 0,008	0,05
Pistons and wrist pin RD270-278	0,001 ÷ 0,010	0,06
Big end bearing and crankpin	0,020 ÷ 0,072	0,17
Valve guide and stem: inlet RD210-211	0,030 ÷ 0,050	0,1
Valve guide and stem: exhaust RD210-211	0,045 ÷ 0,065	0,1
Valve guide and stem: inlet RD270-278	0,020 ÷ 0,040	0,08
Valve guide and stem: exhaust RD270-278	0,040 ÷ 0,065	0,1

Adjustments	MIN (mm)	MAX (mm)
Valves	0,15	0,15
Valve depth from cylinder head	0,9 ÷ 1,1	1,8
Dead space between cylinder face and piston	0,25	0,35
Protrusion of injector RD210-211	2,25	2,75
Protrusion of injector RD270-278	3,75	4,25

End floats	MIN (mm)	MAX (mm)
Crankshaft	0,10	0,20
Camshaft	0,10	0,20
Oil pump shaft	0,01	0,05



RUGGERINI MOTORI
Via Cav. del Lavoro A. Lombardini, 2
42100 REGGIO EMILIA - Italia - ITALY
Tel. (+39) 0522 3891 - Fax (+39) 0522 389433/465
<http://www.ruggerini.it>

è un marchio della



La Lombardini si riserva il diritto di modificare in qualunque momento i dati contenuti in questa pubblicazione.
Lombardini se réserve le droit de modifier, à n'importe quel moment, les données reportées dans cette publication.
Data reported in this issue can be modified at any time by Lombardini .
Lombardini vorbehält alle Rechte, diese Angabe jederzeit verändern.
La Lombardini se reserva el derecho de modificar sin previo aviso los datos de esta publicación.

48	 COMPILER TECNICI <i>M. M. Minella</i>	REG. CODE 1-5302-620	MODEL N° 50902	DATE OF ISSUE 08-03	REVISION 00	DATE 01.08.2003	ENDORSED <i>[Signature]</i>
----	--	-------------------------	-------------------	------------------------	--------------------	--------------------	--------------------------------