





pt 107 / hms 1070



update: 30.12.2015

Skizze	Art.Nr.	Benennung	description
8	390 2204 018	Kette	chain
24	390 2204 034	Drehgriff	handle knob
37	390 2204 047	Skala	scale
46	390 2204 056	Feststellgriff	locking knob
49	390 2204 059	Drehgriff	handle knob
52	330 9653 031	Nadellager	needle bearing
56	390 2204 066	Vorschubwalze	feed roller
57	390 2204 701	Hobelmesser	planer knife
58	390 2204 067	Feder	spring
59	390 2204 068	Spannhülse	sleeve
60	390 2204 069	Keilleiste	taper gib
61	390 2204 070	Schraube	screw
62	390 2204 071	Hobelwelle	planer shaft
64	390 2204 073	Tischplatte links	table plate left
87	390 2204 096	Zeiger	pointer
88	390 2204 097	Skala	scale
90	390 2204 099	Drehknopf	handle knob
91	390 2204 100	Gewindestange	adjustable rod
93	390 2204 102	Antriebsstange	driving rod
95	390 2204 104	Kappe	cap
101	390 2204 110	Drehknopf	handle knob
102	390 2204 111	Hobelwellenschutz	planer shaft guard
107	390 2204 116	Hobelwellenschutzblech	cutterblock mudguard
118	390 2204 127	Endschalter	micro switch
119	390 2204 128	Riemenscheibe	pulley
120	390 2204 129	Rippenband	ripped v-belt
122	390 2204 131	Kettenrad	chain wheel
124	390 2204 133	Kette	chain
125	390 2204 134	Antriebsrad	pinion
126	390 2204 135	Riemenscheibe	pulley
129	390 2204 138	Rippenband	ripped v-belt
131	390 2204 140	Schutzabdeckung	protecting hood
135	390 2204 144	Kettenrad	chain wheel
136	390 2203 108	Buchse	sleeve
137	390 2204 146	Zahnrad	gear wheel
138	390 2204 147	Schaltplatte	connection plate
139	390 2204 148	Feder	spring
158	390 2204 167	Überlastschalter	overload switch
162	390 2204 171	Schalter	switch
163	390 2204 172	Exzenterwelle	eccentric shaft
164	390 2204 173	Tischplatte rechts verstellbar	table plate right
169	390 2204 178	Kohlebürsten (Satz = 2 Stück)	carbon brushes (set = 2 pcs.)
6, 33, 89, 165, 180	390 2204 010	Motor kpl.	motor cpl.
63, 68, 83-86	390 2204 192	Absaughaube kpl.	suction hood cpl.
27-28, 31, 44-46, 65-82	390 2204 193	Anschlag kpl.	fence cpl.
39, 49, 74, 95-106, 181-182	390 2204 194	Hobelwellenschutz kpl.	planer shaft guard cpl.
o.Abb.	390 2204 195	Einstelllehre	adjusting gauge